



Tool Tips Operation & Safety

Electric "Runabout" Mast Lift

COMPACT POWER
EQUIPMENT RENTAL

Safety Practices:

Always make sure that the trailer is attached securely to vehicle.

Ensure all fastening devices from the trailer to the equipment are secured.

Always wear a safety harness and lanyard when in the operator platform.

Use three points of contact for getting in and out of machines

Always operate the lift on a solid level surface, not grass, dirt or earth.

If the machine is left unattended, it must be parked on level ground with the key removed and the operational controls located on the operators platform removed.

Wear close fitting protective clothing and correct safety footwear.

Check controls for proper response. Shut down the machine if a fault is detected.

Never enter a moving machine.

Come to a complete stop before reversing direction.

Keep hands away from moving parts.

Do not step out of the operator's platform while it is in the raised position.

Ensure there is ample overhead clearance.

Stay clear of all electrical conductor and utility lines.

Never touch a hydraulic leak under pressure.

Questions or Problems?

Contact the Home Depot listed on your contract.

Need More Information?

The instructions on this sheet are abbreviated instructions only and are provided solely as a customer service. They are not meant to replace the tool's operation manual. If you are unsure of the tool's safe and proper operation, please request an operator's manual from one of our sales associates. You can also view or download a copy of the operating manual at www.compactpowerrents.com.

Contact Compact Power Equipment Rental at 888-COMPACT
compactpowerrents.com

Tool Operation:

Step	Action
Drive Unit & Attachments	
1	Stand on operator platform with your required safety harness and lanyard securely attached to the platform framework.
2	Operate machine per instructions listed on the control panel, as well as the operator's manual.
3	Never jerk the controls, use a steady even action.
4	Only use on level/firm ground.
5	Drive only with Platform at stowed height.
Trailer / Transporting	
1	Secure machine to trailer with chains and binders before transporting.
2	Transport machine with operator platform in the down position.
3	Make sure that the jack on the trailer is securely raised and locked into place prior to towing.
4	Ensure all pins, chains, binders and retention devices are fastened securely before towing the equipment.

Tips:

Step	Action
1	Never reach or try to do work above the top of the framework on the operator's platform.
2	Use extreme caution at all times when operating a lift.
3	Make sure platform gate is securely closed while raised.
4	Never exceed the recommended weight restriction of the operators platform. Reference owner's manual for capacities of the platform and extension.
5	Be sure to cover and protect lift from paint overspray or insulation adhesion if required.
6	Check charge state of batteries before operating.